



Questions about your new *Super Washer?*

	Wash Times	
Cycles	Hours	Mins
NORMAL	0	51
Prewash + Heavy	1	15
Heavy	1	01
ECO	0	31
Quick 20	0	20
Baby	0	41
Delicate	0	36
Wool	0	36
Winterize	0	02
Quiet	0	31
Sanitize	1	09
Allergen	0	59

DIAGNOSTIC MENU		
Code	Description	Component
E1	Door close	Door Switch
E2	Drain	Drain Pump
E3	Water inlet	Inlet Valves
E4	Water overflow	Pressure Switch
E5	Motor	Motor +Electronic Module
E7	Washing heater failure	Washing heater
E10	Water level failure	Water level sensor
E16	Communication between display & electronic module	Communication Cable

QUESTIONS / SERVICE

Phone/Text : 1-800-776-3538

www.ApplianceDesk.com

QUICK START GUIDE

INSTALLATION




Remove shipping bolts (3) with adjustable wrench



Pull out 3 shipping bolts




Ensure spacer is removed with each shipping bolt (3)



Close the empty space with the blanking plug enclosed

CONNECTIONS



Connect hot & cold water hoses (included)



Insert hose into U-connector and insert into standpipe over sink 24"-40"




Plug power cord into 110V/60Hz/15A outlet

LAUNDRY PREP



Load clothes in the machine



Important:


Use High-Efficiency (HE) Detergent 1 tablespoon

OPERATIONS



1. Press POWER button
2. Turn knob to wash setting
3. Press START

MAINTENANCE



1. Open coin trap door flap
2. Rotate handle counter - clockwise and pull out
3. Clear interior